

DP003T7 LCD Display Board Manual



 **ASANOR**
LIFT CONTROLLER

1. Brief

7" LCD Hall Call Board (Display Board) can display the running direction the lift of, current level, related level information, time, temperature and special state of lift, like overload, full, fire, etc.

7" LCD pixels (800x480). Users can set images by themselves. Picture format supports 24bit, 16bit of bitmap. The designated picture is stored in the root directory in SD card.

Users can define 4 window regions on their own. They are the arrow window, the floor window, the multi-function display window, and the temperature/time window.

The arrow window shows the running direction (up/down) of the lift. See <file name>table:

Arrow	File Name
UP	ArUp.bmp
DOWN	ArDown.bmp
1	Fn1.bmp
2	Fn2.bmp
3	Fn3.bmp
4	Fn4.bmp
.....
60	Fn60.bmp
-1	Fn91.bmp
-2	Fn92.bmp
.....
-9	Fn99.bmp
INSPECTION	repair.bmp
FIRE	fire.bmp
SELF- LEARNING	sl.bmp
LOCK LIFT	lock.bmp
FULL LOAD	fl.bmp
OVER LOAD	ol.bmp
Background Picture	bg.bmp

The current floor display is able to show 1 or 2 or 3 pictures. Setting parameter can make 2 or 3 pictures in turn changes on the multi-function display window, or fix one picture.

	File name
Floor 1 Picture 1	Fi11.bmp
Floor 1 Picture 2	Fi12.bmp
Floor 1 Picture 3	Fi13.bmp
Floor 2 Picture 1	Fi21.bmp
Floor 2 Picture 2	Fi22.bmp
Floor 2 Picture 3	Fi23.bmp
....
Floor 60 Picture 1	Fi601.bmp
Floor 60 Picture 2	Fi602.bmp
Floor 60 Picture 3	Fi603.bmp

2. Parameter Setting

1) Configuration Files

The files located in root directory in SD card, name as config.txt.

Users can modify the parameters in the first line.

```

config.txt - Wordpad
File (F) Edit (E) Option (O) View (V) Help (H)
%1 System set%
0; (Can Baudrate:0->20K,1->25K,2->40K,3->88K)
0; (x0 function:0->disable,1->enable)
1; (display direction:0->horizontal,1->vertical)
6; (Local Floor number)
1; (Transparent display:0->no,1->yes)
-5; (temperature offset,-99~99,100->no display)
50; (lcd backlight,it is between 0 and 100)
0; (week language:0->English,1->Germany)
0; (reserved)

%2 Arrow window set%
0; (start ..)
  
```

① System Set

Line No.	Value	Remark
2	0	Can Baudrate:0->20K,1->25K,2->40K,3->88K
3	0	x0 function:0->disable,1->enable
4	1	display direction:0->horizontal,1->vertical
5	6	Local Floor number
6	1	Transparent display:0->no,1->yes
7	-5	temperature offset,-99~99,200->no display
8	50	LCD back light ,it is between 0 and 100
9	0	week language:0->English,1->Germany
10	0	Date display mode: 0->year-month-day,1->day-month-year, other->not display time and date


② setting for arrow window. Due to square window, users need to make sure coordinate on top left corner and which on bottom right corner. The coordinate unit is pixels.

Line No.	Value	Remark
13	0	Start X
14	0	Start Y
15	400	End X
16	300	End Y
17	0	Display Parameter

E.g. Horizontal Display (forth line is 0, Users hope that the results are shown in following Figure)




In arrow window, the top left corner coordinates (0, 0), the bottom right corner coordinate (400,300), check below picture:



: -1


③Floor NO. Window setting

Line No.	Value	Remark
20	400	Start X
21	0	Start Y
22	800	End X
23	300	End Y
24	0	Display Parameter




④ setting for the multi-function display window.

Line No	Value	Remark
27	0	Start X
28	300	Start Y
29	800	End X
30	420	End Y
31	0	Display Parameter: =0,show one picture =2,show two pictures i =3,show three pictures in turn



⑤ The temperature / time window.

Line No.	Value	Remark
34	0	Start X
35	420	Start Y
36	800	End X
37	480	End Y
38	16711680	Display Parameter: Font Color: red*65526 + blue*256 + green



3) LCD MUNE

User can easily modify the floor where the hall call boards load on, time and date, temperature shift, LCD backlight through the LCD menu.

Press KEY1 about 4 seconds to open menu for setting, then through the elevator up and down button to choose item. Next, press KEY1 to inter submenu, then through the elevator up and down button to adjust value.


Press KEY1 again after finish adjustment. Finally, store and quit through 'save & exit' menu.

3. Picture Making

The board support 24bit (True Color) and 16bit (high color) bitmap. We propose 16bit bitmap.

If the original picture format is JPEG, PNP, users need transfer them to .bmp format. The picture as the original size will be showed from the top left corner of the window. We propose the size of the picture and the definition window are same size.

Installation Dimension:





ASANOR

LIFT CONTROLLER

Head Office Address: No.49, 1th Floor, Valiasr Complex, Firoozeh St.,
Valiasr Ave., Tehran , Iran

Tel: +98 21 88942045/88945807

www.asanoor.com